









Switches and Breakers



Magnetic starters and contactors

<p>H series Electromagnetic contactors</p>  <p>H150C Non reversible type : 10A to 800A frames Reversible type : 10A to 800A frames</p>	<p>Electromagnetic starters</p>  <p>H65C-T Non-reversible type : 10A to 600A frames Reversible type : 10A to 600A frames</p>	<p>Electromagnetic starters with enclosure</p>  <p>Non-reversible type : 10A to 600A frames Reversible type : 10A to 600A frames</p>	<p>Contactor relays</p>  <p>X4 3 contacts to 8 contacts</p>	<p>Thermal overload relays</p>  <p>TR80B-1E TR80B-2E 1E : Overload and lock protections type 2E : Overload, lock and phase-failure protections type</p>	<p>HK series Electromagnetic starters</p>  <p>HK20-T Non-reversible type : 10A to 50A frames Reversible type : 20A to 50A frames</p>
---	--	---	---	--	---

Molded case circuit breakers

<p>F series (Standard) 30A to 4000A frames</p>  <p>F-50FC FXK225-S FX600</p>	<p>S series (Economical) 30A to 800A frames</p>  <p>S-30E SXK225 SX600</p>	<p>L series (High interrupting capacity) 50A to 800A frames</p>  <p>L-50E L-100E L-400E</p>	<p>M series (Motor breaker) 30A to 225A frames</p>  <p>MS-30E MS-50SB MS-100SB</p>	<p>B series (for distribution panel) 50A to 100A frames</p>  <p>B-50E</p>
--	---	--	--	--

Earth leakage circuit breakers

<p>E series (Standard) 30A to 800A frames</p>  <p>EB-50E EXK225 EX400B</p>	<p>R series (High interrupting capacity) 50A to 1200A frames</p>  <p>RX100 RXK225-S RX600B</p>
---	--

Earth leakage relays



Standard five types
Small two types

Air circuit breakers

630A to 5000A frames



AKS-20D

Products in this catalogue are not available in some regions. Ask each sales office for the detail.